

EUROSPRAY L airless piston pump - Chassis




Détails des pièces

Pos.	Référence	Désignation
1	EU51161	EUROSPRAY S Mini, S & L front crankcase
2	EU51273	EUROSPRAY L complete pump
3	EU51156	EUROSPRAY S Mini, S & L suction rod gasket
4	EU51154	EUROSPRAY S Mini, S & L suction rod circlip
5	EU51157	EUROSPRAY S rigid suction rod
6	EU51158	EUROSPRAY S return hose
7	EU51160	EUROSPRAY S Mini, S & L return hose fastening clip
8	EU51171	EUROSPRAY S Mini, S & L return hose deflector
9	EU51155	EUROSPRAY S Mini & S suction strainer
10	EU51147	EUROSPRAY S, L & PULSE foot plug
11	EU51145	EUROSPRAY S, L & PULSE wheel
12	EU51149	EUROSPRAY S, L & PULSE wheel clip
13	EU51151	EUROSPRAY S Mini, S & L tip extension fastening clip

Pos.	Référence	Désignation
14	EU51164	EUROSPRAY S Mini & S complete pump filter without pressure sensor
15	EU51153	EUROSPRAY S arm sleeve M3x4 screw
16	EU51165	EUROSPRAY S Mini, S, L & PULSE complete tool box
17	EU51146	EUROSPRAY S, L & PULSE arm sleeve
18	EU51152	EUROSPRAY S Mini, S & L power cable
19	EU51148	EUROSPRAY S, L & PULSE power cable support


EUROSPRAY L airless piston pump - Transmission



Détails des pièces

Pos.	Référence	Désignation
1	EU51275	EUROSPRAY L pump bucket support
2	EU51274	EUROSPRAY L pump clamping flange
3	EU51276	EUROSPRAY L complete transmission
4	EU51277	EUROSPRAY L electric motor

EUROSPRAY L airless piston pump - Pump




Détails des pièces

Pos.	Référence	Désignation
1	EU51252	EUROSPRAY L pump feet body
2	EU51104	EUROSPRAY S Mini, S & L pump foot O-ring
3	EU51253	EUROSPRAY L pump foot valve ball seat
4	EU51255	EUROSPRAY L pump foot gasket
5	EU51106	EUROSPRAY S Mini & S pump foot valve ball
6	EU51254	EUROSPRAY L pump foot valve ball guide
7	EU51109	EUROSPRAY S Mini & S pump piston nut
8	EU51110	EUROSPRAY S Mini, S & L pump piston ball seat
9	EU51111	EUROSPRAY S Mini, S & L pump piston ball
10	EU51112	EUROSPRAY S Mini, S & L pump piston nut sealing washer
11	EU51113	EUROSPRAY S Mini, S & L pump piston ball guide
12	EU51256	EUROSPRAY L pump piston rod
13	EU51272	EUROSPRAY L pump complete piston

Pos.	Référence	Désignation
14	EU51271	EUROSPRAY L pump gaskets kit
15	EU51265	EUROSPRAY L pump cylinder
16	EU51123	EUROSPRAY S Mini, S, L & PULSE pump HP 1/4" M nipple
17	EU51269	EUROSPRAY L pump cable gland nut
18	EU51270	EUROSPRAY L pump cable gland plug


EUROSPRAY L airless piston pump - Paint filter



Détails des pièces

Pos.	Référence	Désignation
1	EU51164	EUROSPRAY S Mini & S complete pump filter without pressure sensor
2	EU51136	EUROSPRAY S Mini, S, L & PULSE pump complete drain valve
3	EU51123	EUROSPRAY S Mini, S, L & PULSE pump HP 1/4" M nipple
4	EU51130	EUROSPRAY S Mini, S, L & PULSE pump filter plug
5	EU51131	EUROSPRAY S Mini, S, L & PULSE pump filter O-ring
6	EU51132	EUROSPRAY S Mini, S, L & PULSE pump filter support
7	EU51133	EUROSPRAY S Mini, S, L & PULSE 60 mesh pump filter
8	EU51135	EUROSPRAY S Mini, S & L pump pressure sensor
9	EU51134	EUROSPRAY S Mini, S, L & PULSE pump filter body


EUROSPRAY L airless piston pump - Electrical box



Détails des pièces

Pos.	Référence	Désignation
1	EU51140	EUROSPRAY S Mini, S & L ON/OFF switch
2	EU51143	EUROSPRAY S Mini & S fuse
3	EU51137	EUROSPRAY S Mini, S & L fuse holder
4	EU51139	EUROSPRAY S Mini, S & L control panel front
5	EU51141	EUROSPRAY S Mini, S & L electronic display board
6	EU51138	EUROSPRAY S Mini, S & L rear crankcase
7	EU51251	EUROSPRAY L pump electronic card
8	EU51142	EUROSPRAY S Mini, S & L electronic box anti-dust gasket
9	EU51360	RJ11 M/F extension for EUROSPRAY L & XL pump sensor

EUROSPRAY L airless piston pump - Spray-gun



Détails des pièces

Pos.	Référence	Désignation
1	EU51001	EUBST, EUBBP & EUBFF 7/8" nozzle-holder
2	EU51036	PAINTSPRAY spray-gun 7/8" diffuser
3	EU51047	PAINTSPRAY, COATSPRAY spray-gun needle seat gasket
4	EU51046	PAINTSPRAY, COATSPRAY spray-gun needle seat
5	EU51043	PAINTSPRAY, COATSPRAY spray-gun trigger axis circlip
6	EU51042	PAINTSPRAY spray-gun trigger axis
7	EU51040	PAINTSPRAY spray-gun retraction pin
8	EU51033	PAINTSPRAY spray-gun needle repair kit
9	EU51034	PAINTSPRAY,COATSPRAY spray-gun needle return spring
10	EU51038	PAINTSPRAY, COATSPRAY spray-gun needle lock plug
11	EU51031	PAINTSPRAY spray-gun filter holder bearing gasket
12	EU51039	PAINTSPRAY spray-gun complete trigger
13	EU51032	PAINTSPRAY spray-gun trigger protection

Pos.	Référence	Désignation
14	EU51003	Spray-gun grip 50-mesh filter
15	EU51037	PAINTSPRAY spray-gun plastic handle
16	EU51048	Complete revolving coupling for PAINTSPRAY spray-gun
17	EU51035	PAINTSPRAY spray-gun filter holder
18	EU51045	PAINTSPRAY, COATSPRAY spray-gun revolving coupling gasket
19	EU51041	PAINTSPRAY spray-gun filter holding spring
20	EU51044	1/4" MBSP revolving coupling for PAINTSPRAY spray-gun