


MIXER PLUS CLASSIC - 50 Hz continuous mixing machine - Electric panel



Détails des pièces

Pos.	Référence	Désignation
1	3C04000101	1
2	3C04400800	Switch pump PLUS STANDARD
3	3C04400700	Switch scoop wheel PLUS STANDARD
4	3C04400207	Complete phase inverter PLUS STANDARD
5	3C00102805	5
6	3C00500402	Transformer 70/80VA 400/42/24/15
7	3C00601001	Cycle sense phase relay
8	3C00700117	Counter 4 KW 24V AC SIEMENS
9	3C00700117	Counter 4 KW 24V AC SIEMENS
10	3C00700110	10
11	3C03750400	Timer 2 delayed threads 24/230AC/DC
12	3C00102805	12
13	3C04000108	13

Pos.	Référence	Désignation
14	3C02800502	16-pin socket base with 2 levers
15	3C02700600	4/2-pin 80A female insert
16	3C04000106	Orange light indicator with cable 24V
17	3C04000107	17
18	3C04000118	Blue button D.22
19	3C04000105	Green button D.22
20	3C04000104	Red button D.22
21	3C04400207	Complete phase inverter PLUS STANDARD
22	3C01040112	22
23	3C01040112	23
24	3C03000305	3-pin + neutral + ground 32A surface-mount male plug
25	3C01040110	25
26	3C01040107	26
27	3C01040107	27