


EUROSPRAY L airless piston pump - Pump



Détails des pièces

| Pos. | Référence | Désignation |
|------|-----------|--|
| 1 | EU51252 | EUROSPRAY L pump feet body |
| 2 | EU51104 | EUROSPRAY S Mini, S & L pump foot O-ring |
| 3 | EU51253 | EUROSPRAY L pump foot valve ball seat |
| 4 | EU51255 | EUROSPRAY L pump foot gasket |
| 5 | EU51106 | EUROSPRAY S Mini & S pump foot valve ball |
| 6 | EU51254 | EUROSPRAY L pump foot valve ball guide |
| 7 | EU51109 | EUROSPRAY S Mini & S pump piston nut |
| 8 | EU51110 | EUROSPRAY S Mini, S & L pump piston ball seat |
| 9 | EU51111 | EUROSPRAY S Mini, S & L pump piston ball |
| 10 | EU51112 | EUROSPRAY S Mini, S & L pump piston nut sealing washer |
| 11 | EU51113 | EUROSPRAY S Mini, S & L pump piston ball guide |
| 12 | EU51256 | EUROSPRAY L pump piston rod |
| 13 | EU51272 | EUROSPRAY L pump complete piston |

| Pos. | Référence | Désignation |
|------|-----------|--|
| 14 | EU51271 | EUROSPRAY L pump gaskets kit |
| 15 | EU51265 | EUROSPRAY L pump cylinder |
| 16 | EU51123 | EUROSPRAY S Mini, S, L & PULSE pump HP 1/4" M nipple |
| 17 | EU51269 | EUROSPRAY L pump cable gland nut |
| 18 | EU51270 | EUROSPRAY L pump cable gland plug |