


Bomba de pistón airless EUROSPRAY L - Pistola



Détails des pièces

Pos.	Référence	Désignation
1	EU51001	Soporte de boquilla EUBST, EUBBP & EUBFF 7/8"
2	EU51036	Difusor 7/8" G pistola PAINTSPRAY
3	EU51047	Junta asiento aguja pistola PAINTSPRAY, COATSPRAY
4	EU51046	Asiento aguja pistola PAINTSPRAY, COATSPRAY
5	EU51043	Anillo seeger eje gatillo pistola PAINTSPRAY, COATSPRAY
6	EU51042	Eje gatillo pistola PAINTSPRAY
7	EU51040	Pasador de retracción pistola PAINTSPRAY
8	EU51033	Kit reparación aguja pistola PAINTSPRAY
9	EU51034	Muelle de retorno aguja pistola PAINTSPRAY, COATSPRAY
10	EU51038	Tapón de cierre de aguja para pistola PAINTSPRAY, COATSPRAY
11	EU51031	Junta de apoyo portafiltro pistola PAINTSPRAY
12	EU51039	Gatillo completo pistola PAINTSPRAY
13	EU51032	Protección de gatillo pistola PAINTSPRAY



Pos.	Référence	Désignation
14	EU51003	Filtro de 50 mallas para empuñadura pistola
15	EU51037	Mango de plástico pistola PAINTSPRAY
16	EU51048	Conexión giratoria completa pistola PAINTSPRAY
17	EU51035	Portafiltro pistola PAINTSPRAY
18	EU51045	Junta de racor giratorio pistola PAINTSPRAY, COATSPRAY
19	EU51041	Muelle de sujeción filtro pistola PAINTSPRAY
20	EU51044	Conexión giratoria 1/4" MBSP pistola PAINTSPRAY